Sanitary series



Hygienic design, made from electropolished stainless steel AISI 316L to meet the requirements in hygienic installations.



Explosion proof models are available. Certified according to directive 94/9/EC (ATEX), group II, cat 2, for use in EX-zone 1. Contact us for information.


The Tapflo sanitary series is particularly designed to meet the requirements of the food, beverage, pharmaceutical and cosmetic industries. Lubrication free air distribution system, maintenance free ball check valve system and total visual inspection of the wetted parts are some of the major features for this pump series. The materials used on certain models comply with the FDA guidelines. Models with extra fine surface finish Ra 0.8 and Ra 0.5 are available upon request.

Made to be clean Our design allows for total visual inspection of the wetted parts. There are no hidden areas where bacteria can grow. The manifold clamps and the housing screws are simply removed for complete disassembly and cleaning. The pump is also designed for cleaning and sterilization in place – C.I.P. and S.I.P. After such operations, the pump is easily turned in its support for drainage.

Drain the pump by turning the pump in its support (T80-T425)

The sanitary pump range

- ► T30 28 I/min, 1"
- ► T80 78 I/min, 1"
- ► T125 155 I/min, 1 1/2"
- ► T225 330 I/min, 2"
- ► T425 570 I/min, 2 1/2"



5 sizes, 0-425 l/min

Sanitary series



Typical applications

Sector	Example of applications
Dairy products	Milk, cream, yogurt, cream cheese, melted cheese
Grossery	Ketchup, mayonnaise, tomato products, mustard
▶ Beverages	Flavours, colouring, fruit juice
▶ Bakery	Dough, ingredients
► Brewery	Beer, flavours, colouring, wort
► Hygiene	Soap, toothpaste, schampoo
Cosmetics	Cream, alcohol, perfume

Sanitary series



Special versions

Heating jacket

The heating jacket is used when the pumped product has to maintain a specific temperature, high or low, throughout the process. A heating or cooling medium is continuously circulated in the heating jacket. The jacket is covering all the wetted parts of the pump. Available on all sanitary series pumps.



Variety of connection types
The pump is supplied as standard with TC
clamp connections. However, the pump may
be equipped with almost any type of connection used in the hygienic field – DIN, SMS,
RJT, ANSI etc.



Pump on trolley Make your Tapflo pump mobile. The trolley is available for all pump sizes.